



USER GUIDE

FOR iPhone/iPad

Compatibility: Apple iOS 5.1 or higher

1. Overview.....	4
2. Install and Set Up.....	4
2.1. Charge your Power Connect.....	4
2.2. Charge your iPhone battery with Power Connect.....	4
2.3. Download Emtec Connect App.....	5
2.4. Connect your storage devices to your Power Connect	5
2.5. Connect your Power Connect to your iPhone/iPad (no Internet connection required).....	5
3. Emtec Connect main interface	6
3.1. Home page	6
3.2. Access to the files of Power Connect / iPhone /iPad	8
3.3. Videos / Photos / Music / Documents Gallery	8
3.4. Play movie / video	9
3.5. Listen to music.....	9
3.6. View pictures	11
3.7. View documents.....	12
3.8. Download/upload files	12
3.9. Share files	13
4. Back-up.....	14
4.1. Contact back-up.....	14
4.2. Phone back-up (photos and videos).....	14
5. Settings	15
5.1. Emtec Connect settings.....	16
5.1.1. Wi-Fi settings.....	16
5.1.2. LAN setting	19
5.1.3. Internet settings / Router function	20
5.1.4. System settings.....	22
5.2. Cache	26
5.3. Language	26
5.4. About	27
5.5. Log out.....	27

WARNING!

To avoid damage or malfunction:

Do not expose the product to excessive heat caused by heating equipment or direct sunlight.

Do not drop the product or allow objects to fall on your device.

Do not allow the product to be submerged in water. Do not expose device to water, as water entering the set may cause major damage.

Avoid damp environments.

Protect the device against electromagnetic sources.

Back up your files. Ensure that you retain the original files you have downloaded to your device. EMTEC is not responsible for any loss of data if the product becomes damaged or not readable / legible.

Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives as these may harm the product.

About operating and storage temperatures:

Best operating conditions: 41° to 104°F (5°C à 40°).

Technical Support:

Online assistance:




support@emtec-international.com



https://twitter.com/EMTEC_Support

1. Overview

A. Battery level LED
Red: Low battery Flashing Green: Charging Solid Green: Drive On Off: Battery full or Drive Off
B. Wi-Fi LED
Blue: Wi-Fi ready
C. Internet LED
Green: connected to Internet
D. USB 2.0 port
E. Power Button
Press and hold for 2 seconds to power on/turn off the device. On: Power Connect mode. Off: Synchronization mode (The HDD works as a standard portable HDD).
F. microUSB connector
G. microSD slot
H. Reset
I. Ethernet port (RJ45)



2. Install and Set Up

2.1. Charge your Power Connect

Connect the included microUSB cable into any available USB port on your computer. The battery LED will start flashing while it is charging and will turn off once it is fully charged. You may use any power adapter (not included) with 5V/2.1A charging current to charge the product.

Note: Wi-Fi function works when the battery is charging. Just turn on the Power Connect before you start charging.

2.2. Charge your iPhone battery with Power Connect

Connect your iPhone to Power Connect USB port with your USB cable and turn on your Power Connect.

Note: Thanks to Power Connect 5200mAh battery, charge your iPhone up to 2 times!

2.3. Download Emtec Connect App

Download “Emtec Connect” application on the App Store.



2.4. Connect your storage devices to your Power Connect

The microSD slot and USB port allow to convert your own storage devices (microSD, USB flash drive, USB HDD, USB reader) into wireless storage devices to access your data from your smartphone/tablet wirelessly.

1. Ensure your Power Connect is off.
2. Insert the microSD card in the microSD slot or connect USB storage device into the USB port.
3. Turn on your Power Connect.
4. When the Wi-Fi LED stops flashing turn off your Power Connect.

Steps 3 and 4 will create a folder “Share” with “Photos”, “Videos”, “Music” and “Documents” directories on your storage device to index your files and see them through the Emtec Connect App. When you want to copy files from your computer, paste them in these folders to see them through the Emtec Connect App from your smartphone/tablet.



Note: You cannot use your smartphone/tablet as a storage device in Power Connect USB port.

2.5. Connect your Power Connect to your iPhone/iPad (no Internet connection required)

1. Turn-on your Power Connect. Once the Wi-Fi blue LED stops flashing, the Wi-Fi function is ready.
2. Go to Wi-Fi settings on your smartphone/tablet and activate your Wi-Fi connection. Then choose the name of your Power Connect in the network list.
3. Enter the password **(default: EMTEC4567)**.


Note: The device will remember the password and you will not need to enter it again a second time.

4. When the connection is established, open Emtec Connect app to enjoy your files.



3. Emtec Connect main interface

3.1. Home page



Note: Once your iPhone/iPad is connected with your Power Connect, the “Online” pictogram will be green.

Video Gallery:

Allows you to see all the videos available on the Power Connect and your iPhone/iPad.

Photos Gallery:

Allows you to see all the photos available on the Power Connect and your iPhone/iPad.

Music Gallery:

Allows you to see all the music available on the Power Connect and your iPhone/iPad.

Documents Gallery:

Allows you to see all the documents available on the Power Connect and your iPhone/iPad.

System menu:

Access to all the settings of your Power Connect.

Explorer menu:

Allows you to manage and upload/download files (copy/paste, new folder...) from your iPhone/iPad to your Power Connect or from your Power Connect to your iPhone/iPad.

Note: From the homepage, you can directly see the different files (compatible directly with the app) you have in "Videos", "Photos" and "Music" by sliding your finger on the thumbnail.




3.2. Access to the files of Power Connect / iPhone / iPad

Emtec Connect / “iPhone”/”iPad” access:

Select file location by clicking on “EmtecConnect” (your Power Connect) or “iPhone”/”iPad”.



3.3. Videos / Photos / Music / Documents Gallery



All files:

Show all the files available (Videos / Photos / Music / Documents) on your Power Connect or iPhone/iPad.

Top 25:

Show the 25 Videos/ Photos / Music / Documents you look at most often.

My Favorites:

Shows your favorite Videos / Photos / Music / Documents.

Favorite icon:



Click on the Favorite icon to add the file in “My Favorites” section.

DLNS/ Digital Media Sharing:




Click on the TV icon to display on your TV.

3.4. Play movie / video

Note: Compatible files: MP4, MOV, M4V. Other formats will be opened in a third party app available on your iPhone/iPad. If no movie player is available on your iPhone/iPad, you can download one on the App Store. Many movie players are available for free.

To play a video, you can go in the “Videos” gallery or in Explorer.

Just click and hold on the video you want to play and choose the movie player you desire to see the video with.













3.5. Listen to music

To listen to music, you can go in the “Music” gallery or in Explorer.

Note: Compatible files: AAC, MP3, M4A, AIFF, WAV. Other files will be opened in a third party app available on your iPhone/iPad. If no music player is available on your iPhone/iPad, you can download one on the App Store. Many music players are available for free.

Simply locate the music file that you would like to play. Click on the file and your music will automatically play.



	Play / Pause button
	Forward button
	Backward button
   	Repeat all songs <i>Note: Click on this icon to select the other functions below</i> Repeat current song Shuffle mode Play current playlist and then stop
	Share button: Facebook: Share on Facebook Email: Send by email Favorite: Add to “My Favorites” Open in: Open in selected application
	Other songs in the file

Note: You can exit the Music Player Interface at any time and will continue to play the music or audio file in the background.

You can even control play/pause on the homepage and slideshow pages via the “Music Play/Pause” icon:

On the homepage you can directly access the music player by clicking on the “Music” shortcut:



3.6. View pictures

To see a picture, you can go in the “Photos” gallery or in Explorer.







Compatible files: TIF, JPG, JPEG, GIF, PNG, BMP, ICO, TIFF.

The supported images can be viewed as thumbnails or as a list as seen on the screenshot below. Any images that are not supported will be viewed as a generic thumbnail or icon.



You can swipe your finger across the screen to manually view the pictures or images or click the play button, to automatically play the slideshow.



	Play/ Pause
	Share Facebook: Share on Facebook Email: Send by email Photos: Add the file in "Camera" folder on your iPhone/iPad. Path: Favorite: add the file in "My Favorites" section
	UPNP/ Digital media sharing
	Music control
	Repeat mode
	Play current slideshow and then stop

Note: Internet connection is required to share photos/images via email or to access any social media networks.

3.7. View documents


To see a document, you can go in the "Documents" gallery or in Explorer.

Note: The documents will be opened in a third party app available on your iPhone/iPad. You can download one on the App Store.

Just click and hold on the file you want to open and choose the application you desire to see the document with.

3.8. Download/upload files


Go in one of the galleries or in Explorer. Select file location by clicking on "EmtecConnect" » (your Power Connect) or "iPhone"/"iPad".

Click on the icon "Tools" 

Select the action you want to do.

Select file destination by clicking on "EmtecConnect" or "iPhone"/"iPad".

Click on the action you want to do.



Unselect all	Deselect all files
Select all	Select all files in the folder
Create folder	Create a new folder
Copy	Copy selected files
Cut	Cut selected files
Paste	Paste selected files
Rename	Rename selected files or folder
Delete	Delete selected files or folder

Transfer Status:

Transfer status is available in the transfer tab.



3.9. Share files

Open the file you want to share and click on the icon

Then choose the action:

Facebook: Share on Facebook

Email: Send by email

Photos: Add to “Photos” gallery on the Power Connect

DLNA/ Digital Media Sharing: Share the file on your TV (available in gallery)

Favorites: add the file in “My Favorites” section.

4. Back-up

4.1. Contact back-up




On the homepage, click on the “Back up” icon.

Click on “Contacts Backup”.

To back up your contacts on your Power Connect, click on “Start Backup”.

To restore your contacts, click on “Restore backup” and “OK”.



4.2. Phone back-up (photos and videos)




On the homepage, click on the “Back up” icon.

Click on “Phone Backup”.

To back up your photos and videos on your Power Connect, click on “Start Backup”.

If you want to cancel, click on “Cancel”.




5. Settings

Access the settings of the Power Connect by clicking on System icon on homepage.


Available settings depend on connection status.

When your iPhone/iPad is not connected or is connected in Guest mode to your Power Connect, only a few settings are available (Cache/ Language/ About)


Settings page when iPhone/iPad is connected




Settings page when no iPhone/iPad is connected or is connected in Guest mode



5.1. Emtec Connect settings




5.1.1. Wi-Fi settings



SSID:


Change the SSID name (device name) of your Power Connect by clicking on SSID. Save your change before exiting.



The screenshot shows the SSID configuration screen. At the top, there is a red header bar with a back arrow on the left, the text "SSID" in the center, and a home icon on the right. Below the header, there is a white box with the text "Enter the SSID". Inside this box, there is a text input field containing the text "PowerConnect-EEA8". Below the input field, there is a grey button labeled "Save".

Channel:


Change the number of channels on your Power Connect. Save your change before exiting. Auto mode is recommended.



The screenshot shows the Channel configuration screen. At the top, there is a red header bar with a back arrow on the left, the text "Channel" in the center, and a home icon on the right. Below the header, there is a white box with the text "Region" and "United States" below it. To the right of "United States" is a right-pointing arrow. Below this box, there is a list of options: "Auto", "1", "2", "3", "4", "5", "6", "7", and "8". The "Auto" option is selected, indicated by a red checkmark to its right.

Mode:


Change the Wi-Fi standard of your Power Connect. Save your change before exiting.



A screenshot of a mobile application interface for selecting a Wi-Fi mode. The top status bar shows signal strength, Wi-Fi, and the time 17:39. The app's header is red with a back arrow, the title "Mode", and a home icon. Below the header is a list of four options: "11Mbps(802.11b)", "54Mbps(802.11g)", "300Mbps(802.11n)", and "11b/g/n". The "11b/g/n" option is selected, indicated by a red checkmark to its right. Below the list is a grey "Save" button.

Security


Change the security mode and the password of the Wi-Fi connection of your Power Connect. Save your change before exiting.



A screenshot of a mobile application interface for configuring Wi-Fi security. The top status bar shows signal strength, Wi-Fi, and the time 17:39. The app's header is red with a back arrow, the title "Security", and a home icon. Below the header is a list of four security modes: "None", "WPA-PSK", "WPA2-PSK", and "Mixed WPA/WPA2-PSK". The "Mixed WPA/WPA2-PSK" option is selected, indicated by a red checkmark to its right. Below the list is a section for password entry. It starts with the label "Enter password" above a text input field. Below the input field is a checkbox labeled "Show password". Underneath the checkbox is a note: "Password must be any combination of letters and numbers, length is 8-63 characters." At the bottom of the screen is a grey "Save" button.


5.1.2. LAN setting

Change the Internet-related settings.




IP Address:

Change the IP address. Save your change before exiting.



Subnet mask:

Change the subnet mask. Save your change before exiting.




5.1.3. Internet settings / Router function

You can access the Internet on your iPhone/iPad via the Power Connect. It allows you to browse the Internet and to stay connected to the Power Connect at the same time. 2 options:

- Wired access: via LAN cable (Ethernet port).
- Wireless access: via Wi-Fi.


You can enable and disable the Internet access by clicking on the On/Off Intern Access button.

Note: When your Power Connect is connected to the Internet, the “Internet connection” icon is

green on the homepage. 

Wireless access:

“Wireless access” is available when no Ethernet cable is connected to the product.



Then you can choose the Wi-Fi connection in the network list. Enter the Wi-Fi password if needed (Password is requested for secured connection).

Wired access:


- Connection:

Connect an Ethernet cable to the Ethernet port of your WiFi HDD.


Select “Wired access” in Internet access mode and “Save”. You are connected.

- Wired access settings (advanced mode):

Once you are connected with the “Wired access,” you can configure the network of the Power Connect. Network settings include DHCP and static IP. DHCP is automatically assigned IP by DHCP server on the router (recommended). Static option may manually input the IP address, subnet mask, Router, DNS1, DNS2 of the Power Connect.



5.1.4. System settings



User:


On top of the connection password to access your Power Connect, you can define an “Admin” and a “Guest” modes, with dedicate passwords for each. So your friends or coworkers can access your Power Connect with limited access to your settings and data (photos/ videos/ music/ documents) via Guest mode.

Indeed in Guest mode, user can only access and modify “Cache,” “Language” and “About” info in settings and files available in “Share” file.

To allow Guest mode, please click on the button “Guest” in “Settings” section.


Admin password setting:

Enter the password and confirm it. Then save.

A screenshot of a mobile application interface for setting an admin password. At the top, there is a red header bar with a back arrow on the left, the word "User" in the center, and a home icon on the right. Below the header, there is a white box containing a dropdown menu with "admin" selected, two password input fields with "Enter password" placeholder text, and a "Save" button at the bottom.

Guest password setting:

Click on the first line and select guest mode.

A screenshot of a mobile application interface for setting a guest password. It features the same red header bar as the previous screen. Below the header, there is a dropdown menu with "admin" selected. Below that is a password input field with "Enter password" placeholder text. A white modal box is displayed over the input field, showing two options: "Admin" with a single person icon and "Guest" with two people icon.

Enter the wanted password.

17:44

<< User >>

guest

Enter password

Enter password

Save

Confirm the password and save.

Now, your application access is also protected by a password.

When application is launched, choose admin mode or guest mode.

Enter password and click OK to access the application.

17:50

EMTEC
connect

Enter user name

guest

Password


Enter password

☐ Remember password

Cancel OK

Host Name

You can change the host name of the Power Connect.




Host name will be used to access your Power Connect via web browser (host name or IP address can be used to access your Power Connect via web browser).

Choose the new name and save.

Enter <http://emtec> (or replace emtec by the new host name you save) in the address bar of your web browser to access your Power Connect via the web browser.

Disk information

Indicates available capacity on your Power Connect.




Online update

In order to see if a new version is available, connect your Power Connect as a router (see section: “Internet settings” to allow Internet access.

Click on “Online update”. The system will search to see if a new firmware version is available.

If there is a higher version than the system firmware version, the upgrade prompt box will pop-up. Follow the indicated instructions to upgrade the firmware.


5.2. Cache



Set the cache size of the application on your iPhone/iPad.
To clear cache, click on the button “Clear Cache”.

5.3. Language

Choose your language among the list.



5.4. About

Firmware and application versions are indicated in the “About” menu.

5.5. Log out

Click on “Log out” to log out of the application.