



@connectTM

USER GUIDE

WEB INTERFACE

1.	Overview.....	4
2.	Install and Set Up.....	4
2.1.	Charge your Power Connect.....	4
2.2.	Charge your smartphone battery with Power Connect	4
2.3.	Connect your Power Connect to your computer (no Internet connection required).....	5
2.4.	Access to the Web interface.....	5
3.	Main interface	5
3.1.	Home page	5
3.2.	Play movie / video	6
3.3.	View pictures	7
3.4.	Listen to music.....	8
3.5.	View documents	9
3.6.	Explorer functions	9
3.6.1.	Download/upload files	9
3.6.2.	Copy/Paste/Rename/Delete files	11
4.	Settings	13
4.1.	Information.....	14
4.2.	User manager	15
4.3.	Network settings	16
4.3.1.	Host Name	16
4.3.2.	Wi-Fi & LAN	17
4.3.3.	DHCP Server.....	22
4.3.4.	Internet.....	22
4.4.	Services settings	25
4.4.1.	Samba	25
4.4.1.	UPNP (Media server)	25
4.5.	System settings.....	26
4.5.1.	Time settings	26
4.5.2.	Firmware upgrade	28
4.5.3.	Reset settings	29
4.6.	Wizard settings	29
4.6.1.	Step 1: Internet settings	30
4.6.2.	Step 2: User setting	32
5.	Log out.....	33

WARNING!

To avoid damage or malfunction:

Do not expose the product to excessive heat caused by heating equipment or direct sunlight.

Do not drop the product or allow objects to fall on your device.

Do not allow the product to be submerged in water. Do not expose device to water, as water entering the set may cause major damage.

Avoid damp environments.

Protect the device against electromagnetic sources.

Back up your files. Ensure that you retain the original files you have downloaded to your device. EMTEC is not responsible for any loss of data if the product becomes damaged or not readable / legible.

Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives as these may harm the product.

About operating and storage temperatures:

Best operating conditions: 41° to 104°F (5°C à 40°).

Technical Support:

Online assistance:




support@emtec-international.com



https://twitter.com/EMTEC_Support

1. Overview

A. Battery level LED
Red: Low battery Flashing Green: Charging Solid Green: Drive On Off: Battery full or Drive Off
B. Wi-Fi LED
Blue: Wi-Fi ready
C. Internet LED
Green: connected to Internet
D. USB 2.0 port
E. Power Button
Press and hold for 2 seconds to power on/turn off the device. On: Power Connect mode. Off: Synchronization mode (The HDD works as a standard portable HDD).
F. microUSB connector
G. microSD slot
H. Reset
I. Ethernet port (RJ45)



2. Install and Set Up

2.1. Charge your Power Connect

Connect the included microUSB cable into any available USB port on your computer. The battery LED will start flashing while it is charging and will turn off once it is fully charged. You may use any power adapter (not included) with 5V/2.1A charging current to charge the product.

Note: Wi-Fi function works when the battery is charging. Just turn on the Power Connect before you start charging.

2.2. Charge your smartphone battery with Power Connect

Connect your smartphone to Power Connect USB port with your USB cable and turn on your Power Connect.

Note: Thanks to Power Connect 5200mAh battery, charge your smartphone up to 2 times!

2.3. Connect your Power Connect to your computer (no Internet connection required)


1. Turn-on your Power Connect. Once the Wi-Fi blue LED stops flashing, the Wi-Fi function is ready.
2. Go to Wi-Fi settings on your computer and activate your Wi-Fi connection. Then choose the name of your Power Connect in the network list.
3. Enter the password **(default: EMTEC4567)**.

2.4. Access to the Web interface

There is no software to install on your computer! Simply open your web browser and enter the 10.10.10.254 IP address.

3. Main interface

3.1. Home page



Video Gallery:

Allows you to see all the videos available on the Power Connect.

Photos Gallery:

Allows you to see all the photos available on your Power Connect.

Music Gallery:

Allows you to see all the music available on your Power Connect.

Documents Gallery:

Allows you to see all the documents available on your Power Connect.

Explorer menu:


Allows you to manage and upload files (copy/paste, create new folder...) from your computer to your Power Connect.


Settings menu:

Access to all the settings of your Power Connect.

3.2. Play movie / video


To play a video, you can go in the “Videos” gallery or in Explorer.
Just click on the video you want to play.



Click on the TV icon  to display on your TV screen (UPNP/Digital media sharing).



3.3. View pictures

To watch pictures, you can go in the “Photos” gallery or in Explorer.




Click on the photo you want to display.





	Go back to the photos list.
	Go to previous/next photo.




3.4. Listen to music

To listen to music, you can go in the “Music” gallery or in Explorer.




Click on the music file you want to play.



	Play
	Pause
	Volume

3.5. View documents

To see a document, you can go in the “Documents” gallery or in Explorer.




Just click on the file you want to access and it will open or download.

3.6. Explorer functions

3.6.1. Download/upload files


From the homepage, select "Explorer."







To access the files on your microSD click on “SDCard_Volume1”.

To access the files on your USB storage device click on “USBDisk1_Volume1”.

Then click on “Share” and you will access the folders Videos, Pictures, Music and Documents.




	Refresh
	Create a new folder
	Upload files from your computer to your Power Connect
	Go back to previous screen

To upload files from your computer to your Power Connect:


1. Select the folder where you want to upload the files




2. Click on the icon
3. Select the file(s) in your computer explorer and click on “Open”








4. The transfer status will show you when the files have been successfully uploaded.



3.6.2. Copy/Paste/Rename/Delete files

Click on the icon  on a folder or a file and choose the action you want to do.




 Copy	Copy the selected folder/file
 Cut	Cut the selected folder/file
 Rename	Rename the selected folder/file
 Delete	Delete the selected folder/file


4. Settings

Access the settings of the Power Connect by clicking on System icon on homepage. Available settings depend on connection status. When you are connected in Guest mode to your Power Connect, only a few settings are available.

Settings page when connected



Settings page when connected in Guest mode



4.1. Information

This section provides detailed information regarding the Power Connect and the storage.

Device information

The screenshot shows the 'Device' information screen in the Emtec Connect application. The left sidebar contains icons for Information, User Manager, Network Settings, Services Settings, System Settings, and Wizard Settings. The main content area displays a table of device details.

Host Name	Emtec
Serial number	6550025009
Vendor	Emtec
Model	PowerConnect
CPU	5.01 %

Storage information

Indicates available capacity on your Power Connect.


The screenshot shows the 'Storage' screen in the Emtec Connect application. The left sidebar is identical to the previous screen. The main content area displays storage information for two devices: SDCard and USBDisk1. Each device has a progress indicator showing usage percentage and available size.

SDCard 7.5GB	2%	Available size 7.4GB
USBDisk1 7.2GB	15%	Available size 6.2GB

Below the storage information, there is a red button labeled 'Delete'.


4.2. User manager

In addition to the connection password to access your Power Connect, you can define an “Admin” and a “Guest” modes, with dedicate passwords for each. So your friends or coworkers can access your Power Connect with limited access to your settings and data (photos/videos/music/documents) via Guest mode.



Admin password setting:

Enter the password and confirm it. Then save.



Guest password setting:

Activate the Guest mode by clicking on “ON”.


Enter the wanted password.

Confirm the password and save.

Now, your application access is also protected by a password.

When application is launched, choose admin mode or guest mode.


Enter password and click OK to access the web interface.



4.3. Network settings

4.3.1. Host Name

You can change the host name of the Power Connect.




Host name will be used to access your Power Connect via web browser (host name or IP address can be used to access your Power Connect via web browser).

Choose the new name and save.

Enter <http://emtec> (or replace emtec by the new host name you save) in the address bar of your web browser to access your Power Connect via the web browser.

4.3.2. Wi-Fi & LAN

The settings in Wi-Fi & LAN section can be modified based on your needs. See the screenshot below for the available options.




The screenshot shows the 'Wi-Fi & LAN' configuration page in the Emtec Connect web interface. On the left is a sidebar with navigation icons for Information, User Manager, Network Settings (highlighted), Services Settings, System Settings, and Wizard Settings. The main area contains the following settings:

- Hide SSID:** A toggle switch set to 'OFF'.
- SSID:** A text field containing 'PowerConnect-EEA8'.
- Mode:** A dropdown menu showing '11b/g/n'.
- Password:** A text field with masked characters (dots).
- MAC Address:** A text field containing '00:1C:C2:11:EE:A8'.
- IP Address:** A text field containing '10.10.10.254'.
- Subnet Mask:** A text field containing '255.255.255.0'.
- Region:** A dropdown menu showing 'United States'.
- Channel:** A dropdown menu showing '3'.
- Security:** A dropdown menu showing 'Mixed WPA/WPA2-PSK'.

A red 'Save' button is located at the bottom of the settings area.


SSID:

You can change the SSID name (device name) of your Power Connect. Type-in a combination of letters and numbers only (32 characters maximum). Save your change before exiting.




Mode:

The default setting is 11b/g/n. You can manually set the modes to 11Mbps (802.11b), 54MBPS (802.11g), and 150Mbps (802.11n) by selecting in the list. Save your change before exiting.



Password:

Change the password. Save your change before exiting.




The screenshot shows the 'Emtec Connect' application interface. The top bar is red with the 'Emtec Connect' logo and a 'Back' button. The main title is 'Wi-Fi & LAN'. On the left, a sidebar contains icons for 'Information', 'User Manager', 'Network Settings' (selected), 'Services Settings', and 'System Settings'. The main content area displays the following settings:

- Hide SSID: ON/OFF toggle (OFF is selected)
- SSID: PowerConnect-EEA8
- Mode: 11b/g/n
- Password: [Redacted with dots]
- MAC Address: 00:1C:C2:11:EE:A8
- IP Address: 10.10.10.254

IP Address:

The default IP address is set to 10.10.10.254. You can change it. Save your change before exiting.




This screenshot is identical to the one above, showing the 'Emtec Connect' application interface with the 'Wi-Fi & LAN' settings. The 'Network Settings' option is selected in the sidebar. The main content area displays the same settings as the first screenshot:

- Hide SSID: ON/OFF toggle (OFF is selected)
- SSID: PowerConnect-EEA8
- Mode: 11b/g/n
- Password: [Redacted with dots]
- MAC Address: 00:1C:C2:11:EE:A8
- IP Address: 10.10.10.254

Subnet mask:

The default subnet mask is set to 255.255.255.0. You can change it. Save your change before exiting.




The screenshot shows the 'Wi-Fi & LAN' settings page in the Emtec Connect application. The left sidebar contains icons for Information, User Manager, Network Settings (selected), Services Settings, System Settings, and Wizard Settings. The main content area displays the following fields:

- MAC Address: 00:1C:C2:11:EE:A8
- IP Address: 10.10.10.254
- Subnet Mask: 255.255.255.0 (highlighted with a blue selection box)
- Region: United States
- Channel: 3
- Security: Mixed WPA/WPA2-PSK

A red 'Save' button is located at the bottom right of the settings area.

Region:

Choose your region among the list.




This screenshot shows the same 'Wi-Fi & LAN' settings page, but with a dropdown menu open for the 'Region' field. The dropdown list contains the following options:

- United States
- Britain
- China
- Japan
- Germany

The other settings fields remain visible in the background, including the MAC Address, IP Address, Subnet Mask, and Security options.


Channel:

Change the number of channels on your Power Connect. Save your change before exiting. Auto mode is recommended.



Security:

Change the security mode and the password of the Wi-Fi connection of your Power Connect. Save your change before exiting.



4.3.3. DHCP Server

The DHCP or Dynamic Host Configuration Protocol is a network protocol that enables a server to automatically assign an IP address to a device connected to a network. By default, the DHCP Server option is enabled. You can disable this option by clicking on “OFF” if you want to manually modify the settings. Save your changes before exiting.

The screenshot shows the 'Emtec Connect' web interface for configuring the DHCP Server. The interface has a red header bar with the 'Emtec Connect' logo, a 'Back' button, and the title 'DHCP Server'. A left sidebar contains navigation icons for Information, User Manager, Network Settings (selected), Services Settings, System Settings, and Wizard Settings. The main content area displays the DHCP Server configuration. At the top right of this area is a toggle switch for the DHCP Server, currently set to 'ON'. Below this are input fields for 'Start Address' (10.10.10.1), 'End Address' (10.10.10.50), 'Gateway' (10.10.10.254), 'Primary DNS' (10.10.10.254), and 'Second DNS' (empty). At the bottom of the configuration area are two red buttons: 'Client List' and 'Save'.


4.3.4. Internet

There are two available Internet Access options:

- Wireless Access, connecting the Power Connect to another wireless device to have the internet access.
- Wired Access, connecting an Ethernet cable into the Power Connect Ethernet port.

Wireless access:


Select “Wireless access” in Internet access mode and “Save”.



The screenshot shows the 'Emtec Connect' interface with the 'Internet' settings page. On the left sidebar, 'Network Settings' is selected. The main content area shows 'Wireless Access' selected with a red dot, while 'Wired Access' is unselected with a grey dot. Below this, 'DHCP' is selected with a red checkmark, and 'Manual' is unselected. The 'SSID' field is empty, and a red 'Scan' button is visible. The 'Dexxon_Prive' network is listed with MAC address 'HPM1217-842C36'. The 'Password' field is empty. A large red 'Save' button is at the bottom.

Then you can choose the Wi-Fi connection in the network list. Enter the Wi-Fi password if needed (Password is requested for secured connection).

You can modify the wireless access to Internet clicking on “Manual”. See the screenshot below.



This screenshot shows the same 'Emtec Connect' interface, but with 'Manual' selected under the Internet access mode. The 'DHCP' option is now unselected. Below the 'Password' field, there are several input fields for manual configuration: 'IP Address', 'Subnet Mask', 'Gateway', 'Primary DNS', and 'Second DNS'. A red 'Save' button is at the bottom.

Wired access:

Connect an Ethernet cable to the Ethernet port of your Power Connect.
Select “Wired access” in Internet access mode and “Save”. You are connected.

The screenshot shows the 'Emtec Connect' interface with the 'Internet' settings page. On the left sidebar, 'Network Settings' is selected. The main area shows 'Wireless Access' as disabled and 'Wired Access' as enabled. Under 'Wired Access', 'PPPoE' is selected, and 'Static IP' is also selected with a red checkmark. The 'Dynamic IP' option is unselected. Below these, the 'IP Address' field is populated with '10.33.64.110', 'Subnet Mask' with '255.255.0.0', 'Gateway' with '10.33.2.1', 'Primary DNS' with '10.33.1.1', and 'Second DNS' with '10.33.20.1'. A red 'Save' button is at the bottom.

By selecting the Wired Access option, the Dynamic IP is selected as the default setting. You can manually assign your own IP address by clicking on the Static IP option.


This screenshot shows the same 'Emtec Connect' interface, but with 'Static IP' selected under the 'Wired Access' section, indicated by a red checkmark. The 'Dynamic IP' option is now unselected. The IP address fields (IP Address, Subnet Mask, Gateway, Primary DNS, and Second DNS) are currently empty, ready for manual input. The 'Save' button remains at the bottom.

4.4. Services settings

4.4.1. Samba

To enable Samba click on “ON”.


This service enables you to map your Power Connect as a network drive and to access the files stored on your Power Connect via your computer explorer.



4.4.1. UPNP (Media server)

To enable UPNP click on “ON”.


This service enables you to open your multimedia files with the multimedia player(s) installed on your computer.




4.5. System settings


4.5.1. Time settings

Click on the drop-down list and select the region you are located and switch-on the “Automatically synchronize with an Internet Time Server”. This will automatically update the time when the Power Connect is connected to the internet.






The “Time Sync Frequency” can be set to everyday, every 2 days, every 3 days, up to every 7 days.




Save your changes before exiting.

4.5.2. Firmware upgrade

Web Upgrade: The device firmware can be upgraded by following the simple steps below.




1. Download and save the latest firmware version on your computer.
2. Click on “Browse”, search and locate the firmware file on your computer and then click on the “Open” button as seen on the screenshot below.
3. The latest firmware update file will appear in the field “New Firmware Upgrade”. Click on “Firmware Upgrade”.



4. Once the firmware has been installed, the warning message as seen on the screenshot below will appear and the device will automatically reboot and will go back into the login screen.

4.5.3. Reset settings

This function will reset all your customized settings or whatever changes you made back to its original settings.




The Power Connect will automatically reboot once the restoring to the factory default settings have been completed.

4.6. Wizard settings

This wizard will guide you through the step-by-step process on configuring the Power Connect as seen on the screenshots below.

Click on the “Next” to start.



4.6.1. Step 1: Internet settings

There are two available Internet Access options:

- Wireless Access, connecting the Power Connect to another wireless device to have the internet access.
- Wired Access, connecting an Ethernet cable into the Power Connect Ethernet port.

Wireless access:

Select “Wireless access”

Then you can choose the Wi-Fi connection in the network list. Enter the Wi-Fi password if needed (Password is requested for secured connection).

The screenshot shows the 'Emtec Connect' interface for 'Internet settings'. On the left is a sidebar with icons and labels for 'Information', 'User Manager', 'Network Settings', 'Services Settings', 'System Settings', and 'Wizard Settings'. The main content area has a red header bar with 'Emtec Connect', a 'Back' button, and the title 'Internet settings'. Below the header, there are two radio buttons: 'Wireless Access' (which is selected, indicated by a red dot) and 'Wired Access'. Under these, there are two more radio buttons: 'DHCP' (selected with a red checkmark) and 'Manual'. The 'Manual' option is currently selected. Below the 'Manual' option, there is a 'SSID' label and a text input field containing 'Dexxon_Prive' and 'HPM1217-842C36'. A red 'Scan' button is positioned to the right of the SSID input field. Below the SSID field is a 'Password' label and an empty text input field. At the bottom of the screen, there are two red buttons: 'Next' and 'Skip'.

You can modify the wireless access to Internet clicking on “Manual”. See the screenshot below.

The screenshot shows the 'Internet settings' screen in the Emtec Connect application. On the left is a sidebar with icons for Information, User Manager, Network Settings, Services Settings, System Settings, and Wizard Settings. The main area is titled 'Internet settings' and has a 'Back' button. It features two radio buttons: 'Wireless Access' (selected) and 'Wired Access'. Below these are fields for DHCP (set to 'Manual'), SSID (set to 'Dexxon_Prive' with a 'Scan' button), and Password. At the bottom are fields for IP Address, Subnet Mask, Gateway, Primary DNS, and Second DNS. 'Next' and 'Skip' buttons are at the very bottom.

Wired access:


Connect an Ethernet cable to the Ethernet port of your Power Connect.
 Select “Wired access” in Internet access mode and “Save”. You are connected.

This screenshot shows the 'Internet settings' screen with 'Wired Access' selected. The 'Wireless Access' radio button is now unselected, and 'Wired Access' is selected. The 'Wired Access' section shows 'PPPoE' as the connection type, with 'Static IP' and 'Dynamic IP' options. 'Dynamic IP' is selected with a green checkmark. Below are fields for IP Address (10.33.64.114), Subnet Mask (255.255.0.0), Gateway (10.33.2.1), Primary DNS (10.33.1.1), and Second DNS (10.33.20.1). 'Next' and 'Skip' buttons are at the bottom.

By selecting the Wired Access option, the Dynamic IP is selected as the default setting. You can manually assign your own IP address by clicking on the green arrow and select the Static IP option.


4.6.2. Step 2: User setting

The next step is to change the admin default password. Click on the “Next” button once the password has been modified. You can click on the “Skip” button to keep the default password.



The screenshot shows the 'User Setting' interface within the 'Emtec Connect' application. On the left is a sidebar with icons and labels for 'Information', 'User Manager', 'Network Settings', 'Services Settings', 'System Settings', and 'Wizard Settings'. The main area on the right contains a form with three input fields: a username field with 'admin', a password field with a lock icon, and a confirm password field with a lock icon. Below these fields are two red buttons labeled 'Next' and 'Skip'. At the top of the main area, there is a 'Back' button and a home icon.

The system will start rebooting. This process will take approximately 2 minutes as seen on the image below.



5. Log out

To log out, click on the icon 